

## Instruction Manual for Slit Spray Nozzles

Series	Remark
SLNH-H	PVC body

Preface	P. 1
Safety Precautions	P. 1
1. Suggestions & Cautions	P. 2
2. Components of Nozzle	P. 3
3. Disassembly	P. 4
4. Assembly	P. 4
5. Maintenance	P. 6
6. Troubleshooting	P. 6
7. Disposal	P. 7
8. Inquiries	P. 7

H. IKEUCHI & CO., LTD.

## Preface

Thank you for purchasing the Spray Nozzle from H. Ikeuchi & Co., Ltd.

This manual gives detailed instructions for the basic handling, maintenance and cautions of the product.

Please be aware that due to continuing efforts to improve our products, some details in this manual may differ from the actual product.

After reading, keep this manual handy for quick reference.

## Safety Precautions

Prior to use, read this manual carefully and familiarize yourself with the proper operation of the product for optimal performance.

H. Ikeuchi & Co., Ltd. takes no responsibility for any accidents and/or injuries resulting from improper handling, installation and/or operation.



### Wear safety gloves.

Screw threads, edges and corners may be sharp and could cause injury.



### Ensure that the nozzle is firmly installed.


Loose screws may cause the nozzle to come off during operation and lead to serious accidents.

## 1. Suggestions & Cautions

- (1) Nozzles are precision-made products. The slit opening is a particularly important part and determines the spray characteristics, such as spray capacity and spray pattern distribution. Handle it with care.
- (2) Nozzles may be heavy and need to be handled carefully.  
For example, piping connections for liquid supply should be installed after the nozzles have been installed.
- (3) Screw threads, edges and corners may be sharp.  
Wearing safety gloves is recommended.
- (4) Operate the nozzles under the specified pressures.  
If the pressure is not specified, refer to the provided flow-rate diagram
- (5) Precautions for piping
  - Use piping and valves large enough to prevent the pressure from dropping.
  - Use new stainless steel pipes as dust and debris in old pipes may clog the nozzles. Never use pipes that can rust.
  - Even new pipes may have chips, seal tape or other debris inside. ALWAYS flush pipes thoroughly before installing nozzles to remove any debris that could cause clogging.
  - Install a pressure gauge in front of the nozzle to adjust the supply pressure appropriately. Installation of a valve is also recommended.
  - Install filters to prevent clogged nozzles. Clogging will impact nozzle performance.

## 2. Components of Nozzle

### Components and Materials



No.	Component	Material	Quantity	Remarks	No.	Component	Material	Quantity	Remarks
1	Body plate (A)	PVC	1		5	O-ring (P4)	FKM	18	Consumable
2	Body plate (B)	PVC	1		6	O-ring	FKM	17	Consumable
3	Bolt (M8)	PVC	24		7	Packing	PE	1	
4	Bolt (M4)	PVC	35						

#### Note:

##### (1) Consumables

The lifetime of a nozzle varies, depending on the operational conditions. If there is a significant change in the nozzle performance, consumable parts should be replaced.

##### (2) Dimensions and materials may differ depending on product codes.

##### (3) The quantities shown in the above table are for a nozzle length of 1,000 mm and are for reference only.

### 3. Disassembly (please refer to the parts list on the previous page)

Clogging of the slit orifice causes uneven spray dispersion and unstable spraying.

If the nozzles becomes clogged, use a clearance gauge (feeler gauge) with a thickness equal or smaller to that of the nozzle slit to remove the clog.

Use only a straight clearance gauge. Do not use a bent or broken gauge to avoid damage to the slit orifice. Use the clearance gauge carefully and slowly.




Figure 1. Distorted spray from clogged nozzle

If it is not possible to remove the clog with a clearance gauge, disassemble and clean the nozzle following the procedure below.

- (1) Place the nozzle on a flat, even surface with the bolt head side up. DO NOT use any vise or similar tools to hold the slit nozzle to avoid damage or deformation of the nozzle.

- (2) Loosen all the slit adjustment bolts #4, then remove the assembling bolts #3.

Necessary tool: Flat-blade screwdriver


- (3) Remove body plate #1.

- (4) Carefully clean out any dust or foreign particles from the inside with a cloth. Make sure not to damage the tip of the slit.


### 4. Assembly (please refer to the parts list on the previous page)

Ensure that any foreign matter has been removed from the surface and inside of the slit opening with a cloth before reassembling.


- (1) Put O-rings on bolts #4. There is NO O-ring for bolt #3.)



Bolt #4 with  
O-ring #5 (P4)




Bolt #4 with  
O-ring #6




Slip O-ring all the way to the head.

- (2) Carefully place packing #7 on top of body plate #2, and then place body plate #1 on top of them. Alternate [bolts #4 + O-ring #5 (P4, larger O-ring)] and [bolts #4 + smaller O-ring #6], placing them in the bolt holes of plate #1. Bolts #4 with larger O-ring #5 must be placed at both ends. Lightly screw [bolts #4 + O-ring #6] into the body plates. Do not tighten them yet! This will be explained in step (4).



Bolts #4 are slit adjustment bolts. Tightening [bolts #4 + larger O-ring #5] widens the slit opening while tightening [bolts #4 + O-ring #6] narrows the slit opening.

Necessary tool: Flat-blade screwdriver



- (3) After lightly tightening the assembling bolts #3 (M8), make sure that the edges (A) of body plate #1 and #2 align. Then, fully tighten the assembling bolts #3 (M8), by screwing them in until there is resistance. Finish with an additional 1/8 of a turn.

Necessary tool: Flat-blade screwdriver

- (4) Adjust [bolts #4 + O-ring #5] and [bolts #4 + O-ring #6] to set the slit opening width within +/- 10% of the designed width.

The slit opening width must be wide enough for a "pass through check gauge" to pass through smoothly, but a "no-pass through check gauge" cannot pass through at all (see chart below).

Make sure that each adjustment bolt has tension on it. Without this tension, the slit may expand when liquid pressure is applied. It may also cause loosening of the bolts and liquid leakage.

Necessary tools: Flat-blade screwdriver, clearance gauge

Designed slit opening width	Pass through check gauge	No-pass through check gauge
0.1	0.08	0.12
0.15	0.13	0.17
0.2	0.17	0.23
0.3	0.26	0.34

Thicker size gauges in steps of 0.01 are difficult to obtain. If a specific size is not available, put two gauges together that add up to the correct size. For example, use 0.2 and 0.03 mm gauges together for 0.23 mm.

	<u>To widen</u> the slit opening width	<u>To narrow</u> the slit opening width
Bolt #4 w/ O-ring #5	<b>Tighten</b>	Loosen
Bolt #4 w/ O-ring #6	Loosen	<b>Tighten</b>

The pitch of the M4 screw is 0.7 mm, and the slit opening width can be adjusted in increments of 0.01 mm by turning the screw 5 degrees.

- (5) It takes about an hour to disassemble, clean and reassemble the nozzle.

Check the slit opening to make sure it is straight and even before installing the nozzle in the equipment.

Note:

- Make sure not to drop, damage or lose any of the small parts.
- The slit opening is the most important part of the nozzle. If it is damaged, the spray pattern will be split or disrupted. Take extreme care when handling the nozzle.

## 5. Maintenance

Check	Item	Check points
Daily	Spray	Confirm that the spraying pressure is normal.
	Pressure gauges and flow meters	Confirm that the liquid pressure and flow rate are correct during operation.
Periodically	Spray	Feel the spray pattern on your hand to check for split or uneven distribution.
	Appearance	Confirm that there is no corrosion and dust adhesion to the slit opening.

Maintenance intervals vary depending on the operating conditions.

## 6. Troubleshooting

Trouble	Probable Cause		Solution
No spray is being created	Control	<ul style="list-style-type: none"> <li>• Controller is not switched on.</li> <li>• Valves are not opened.</li> </ul>	<ul style="list-style-type: none"> <li>• Switch it on.</li> <li>• Open the valves.</li> </ul>
	Nozzle	<ul style="list-style-type: none"> <li>• Nozzle or pipe is clogged.</li> <li>• Nozzle or pipe is clogged due to damage.</li> <li>• Slit opening is clogged.</li> </ul>	<ul style="list-style-type: none"> <li>• Check and clean the nozzle or pipe.</li> <li>• Replace the damaged part.</li> <li>• Disassemble and clean the nozzle.</li> </ul>
Liquid leaks	<ul style="list-style-type: none"> <li>• Some parts are loose or not tightened.</li> </ul>		<ul style="list-style-type: none"> <li>• Tighten the connections.</li> </ul>
	<ul style="list-style-type: none"> <li>• Loose bolts on the nozzle.</li> <li>• O-ring is damaged.</li> <li>• Improper assembling of the nozzle.</li> </ul>		<ul style="list-style-type: none"> <li>• Tighten the bolts.</li> <li>• Replace the damaged part.</li> <li>• Reassemble the nozzle.</li> </ul>
	<ul style="list-style-type: none"> <li>• Nozzle or pipe is cracked.</li> <li>• Nozzle or pipe is corroded.</li> </ul>		<ul style="list-style-type: none"> <li>• Replace the cracked part.</li> <li>• Replace the corroded part.</li> </ul>
Irregular spray pattern	<ul style="list-style-type: none"> <li>• Slit opening is clogged.</li> <li>• Dent on the slit.</li> <li>• Dust or foreign particles adhered on the nozzle.</li> </ul>		<ul style="list-style-type: none"> <li>• Disassemble and clean the nozzle.</li> <li>• Replace the damaged part.</li> <li>• Clean the nozzle.</li> </ul>

## 7. Disposal

Disposal should be practiced according to the regulations and codes of local authorities, or ask a disposal professional.

## 8. Inquiries

For spare parts or any trouble, contact your supplier or the following:

H. IKEUCHI & CO., LTD.

Daiichi Kyogyo Bldg., 1-15-15, Awaza, Nishi-ku,

Osaka 550-0011 JAPAN

Tel: +81-6-6538-4015 Fax: +81-6-6538-4022

Email: [overseas@kirinoikeuchi.co.jp](mailto:overseas@kirinoikeuchi.co.jp)

<https://www.kirinoikeuchi.co.jp/eng/>